

RECEPTACLE CHART

Input Plug and Output Receptacle Chart



| | | | |
|---|---|--|---|
| 5-15R  | 5-15P  | 5-20R  | 5-20P  |
| L5-30R  | L5-30P  | 6-15R  | 6-15P  |
| L6-20R  | L6-20P  | L5-20R  | L5-20P  |
| IEC-320-C13 (female)  | IEC-320-C14 (male)  | IEC-320-C19 (female)  | IEC-320-C20 (male)  |
| L14-30R  | L14-30P  | IEC-309, 16A  | IEC-309, 32A  |
| L6-30R  | L6-30P  | | |

R indicates receptacle
P indicates plug
L indicates locking plug or receptacle

Please call 800-387-2537 or 440-247-7000 for technical support.